

# SMONO

VAPE VITAL

ENGLISH

## SAFETY

Charge the battery with a quality charger never more than 5 Volt and 1 Ampere.

Smono Vital is not a medical device and is not intended to diagnose, cure, treat or prevent any disease or other condition. If you have any health problems, consult your doctor before using the Smono Vital.


This product should not be used by children, women who are pregnant or breast feeding, or those with life threatening illnesses without first consulting a doctor. Never use before driving or operating machinery.

Smono Vital is not intended to administer medicinal or illegal substances of any kind. Any illegal use of this device could subject the user to severe fines, penalties, and/or imprisonment under the law of your jurisdiction.

Use only vaporizer cleaner like LaPiLu.

For Temperature switchover between Fahrenheit and Celsius press the Power button and „°“ button at the same timer for 2 seconds.

## OVERVIEW



## INCLUDED



Packing Foam Cleaning brush USB cable Tweezer

## SPECIFICATION

Battery Capacity	18650 3.7V 2600mah
Charger/Output Voltage	5.0V/1A
Charging	Micro USB charging
On/Off	Press the Power button 3 seconds
Safety Power Duration	5 minutes and 10 minutes optional
Heating Chamber	Ceramic with embedded heating element
Screen	OLED


## CHAMBER

1. Remove Smono Vital's mouthpiece

2. Always fill the chamber with moderate ground herb, DO NOT compress the plant material too much so that the airflow is not unnecessarily impeded. Then insert mouthpiece back into the heating chamber.



3. Hold the Power Button for 3 seconds to turn on the Smono Vital and it will begin to heat up at once under the default settings. The "°" will keep blinking during the heat-up stage. Wait for the "°" become solid and you are ready to puff until the "°" stops blinking.



4. To fill herb pressure, press the "+" to increase herb pressure, press the "-" to decrease herb pressure. (Smono Vital will automatically remember your last setting when restart.)

5. The "°" will solid once the selected temperature reaches. Then inhale slowly and deeply from the mouthpiece. If the OLED screen off.



6. To repeat temperature switchover between Fahrenheit and Celsius, hold the Power button and "°" button at the same time for 2 seconds.



7. Timer switchover between 5 minutes and 10 minutes, Hold the Power button and "°" button at the same time for 2 seconds.



## CHARGING

1. To protect and extend the battery, it is recommend your Smono Vital be charged with wall adapter for at least 5 hours before its first use.

2. When Charging, the OLED screen will light on. The battery icon will change to show battery charging condition. The icon gauge will be full when battery fully charged. The Smono Vital will automatically power off if no operation within 60 seconds after fully charged.

After using the Smono Vital vaporizer and power adapter, allow them to cool down before storage. Store the Vital vaporizer in a dry and cool place to protect against the effects of weather and out of reach of children or unqualified persons.

## CLEANING

To maintain the Smono Vital, it is recommended to clean the chamber and the mouthpiece after every use.

1. Clean the rubber mouthpiece, use a cotton swab and wipe the inner part of the rubber mouthpiece then wipe again with a damp paper towel.

2. Clean the filter, after using, use the brush tool to gently clean the filter. For a deeper clean, use your hands or clamp as per towel to gently clean the filter with a mixture of soap and water.

3. Clean ceramic heating chamber, deactivate the Smono Vital by locking it. Make sure the vaporizer has not been used for at least 30 minutes and is completely cooled off, use the clean brush to gently clean the walls of the heating chamber. You may use small wipes to clean out any leftover particles.

DO NOT clean the whole device with water or sanitizer.

DO NOT inject any liquid or oil into the ceramic chamber.





[MagicVaporizers](#) – Europe's Best Shop for Vaporizers

- Lowest prices
- Fastest shipping
- Most trusted warranty

